

Model
TV LED Lobod 32DE1 T2/S2 Frameless
TV LED Lobod LE32A719 T2/S2
TV LED Lobod LF32DN5321 T2/S2 HD Ready
TV LED Lobod LF32DN5321 T2/S2 Smart
TV LED Lobod LF39DN5321 T2/S2 HD Ready Smart
TV LED Lobod LF42DN4322 Smart T2S2 Full HD Smart
TV LED Lobod LF43DN4322 Full HD Smart
TV LED Lobod LF43DN4322 T2S2 Full HD
Klima Lobod Optima 12 TPL12-HEA2 inverter
Klima Lobod Optima 18 TPL18-HEA2 inverter
Frižider Lobod FL90
Frižider Lobod FLL235
Kombinovani frižider Lobod KFL210
Kombinovani hladnjak Lobod KFL138
Električni šporet Lobod LR 5055 W/n
Električni šporet Lobod ESR5060B
Električni šporet Lobod FSCS5055W3/n
Električni šporet Lobod FSCS5060W5/n
Električni šporet Lobod FSCS6060W5/n
Kombinovani plinsko-električni šporet Lobod LRP 6060W/n
Mašina za pranje i sušenje Candy CSOW 4855TWE/1-S
Mašina za pranje i sušenje Candy ROW41494DWMCE-S
Mašina za pranje i sušenje Candy RPW4856BWMR/1-S
Mašina za pranje i sušenje Candy RPW4966BWMR/1-S
Mašina za pranje posuđa Candy CF 3C7L0W
Mašina za pranje posuđa Candy CF 3E7L0W
Mašina za sušenje veša Candy CSOE H11A2TE-S 11kg/toplotna pumpa
Mašina za sušenje veša Candy CSOE H9A2DE-S 9kg/toplotna pumpa
Mašina za sušenje veša Candy RPE H10A2TE-S 10kg/toplotna pumpa
Veš mašina Candy RO 14146DWMCT/1-S
Veš mašina Candy RO 1496DWMCT/1-S
Veš mašina Candy RO16106DWMCT/1-S
Veš mašina Candy RP 4116BWMBCB-S inverter motor
Zamrzivač Candy CCOUS 6172WH
Zamrzivač Candy CUHS 38FW
Zamrzivač Candy CUHS 38FW
Aspirator Candy CBT6130/3X
Aspirator Candy CBT625/2W
Ugradna mašina za pranje posudja Candy CDIH 2T1145
Ugradna mašina za pranje posudja Candy CDIH 2D949
Ugradna mašina za pranje posuđa Candy CDIH 1L952
Ugradna mašina za pranje posuđa Candy CI 3C9F0A
Ugradna mašina za pranje posuđa Candy CI 3E7L0W
Ugradna mikrotalasna pećnica Candy MIC 201 EX
Ugradna ploča Candy CDH 30

ean:
Ugradna ploča Candy CDH 30
ean:
Ugradna ploča Candy CH63TVT
Ugradna ploča Candy CH64BVT
Ugradna ploča Candy CH64CCW Bijela
Ugradna ploča Candy CH64DVT
Ugradna ploča Candy CI642C/E1 indukciona
Ugradna ploča Candy CID 30/G3 indukciona
Ugradna ploča Candy CID 30/G3 indukciona
Ugradna ploča Candy CIES55MCTT indukciona
Ugradna ploča Candy CIES642MCTT indukciona
Ugradna ploča Candy CTP64SC/E1 indukciona
Ugradni frižider Candy CRU 160 NE/N